


Axle Assembly



Axle Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	ST22031-03	1	Axle	5	3256-28	2	Washer-Flat
2	100-6116	4	Screw-HHF	6	ST80054	2	Nut
3	99-5107	4	Nut-Lock	7	3272-13	2	Pin-Cotter
4	125-8171	2	Hub ASM	8	ST32306	2	Tire And Rim ASM